Secure Printing on HP Printers

Joshua Baird - 2025-02-17 - Public

Print a Stored Job

Use the following procedure to print a job that is stored in the printer memory.

1. From the Home screen on the printer control panel, select the **Print** icon.

2. Select **Print from Job Storage**.

3. Select **Choose**, and then select the name of the folder where the job is stored.

4. Select the name of the job and enter the PIN.

5. To adjust the number of copies, select the number of copies field in the bottom-left corner of the screen. Use the keypad to enter the number of copies to print.

6. Select **Start** or **Print** to print the job.

- Tags
- knowledge base